




MOTOR 210CC MOTOBOMBAS




P1

PAG	POS	REFERENCIA	DESCRIPCION
P1	4	D35M210/P1/4	JUNTA CULATA MOTOR DUCATI 210CC DCW/DHL
P1	5	D35M210/P1/5	TAPA VALVULAS MOTOR DUCATI 210CC DCW/DHL
P1	6	D35M210/P1/6	JUNTA TAPA VALVULAS MOTOR DUCATI 210CC DCW/DHL
P1	7	D35M210/P1/7	TUBO RESPIRADERO MOTOR DUCATI 210CC DCW/DHL
P1	8	D35M210/P1/8	TORNILLO TAPA VALVULAS MOTOR DUCATI 210CC DCW/DHL
P1	9	D35M210/P1/9	ESPARRAGO CARBURADOR MOTOR DUCATI 210CC DCW/DHL
P1	10	D35M210/P1/10	ESPARRAGO SILENCIOSO MOTOR DUCATI 210CC DCW/DHL
P1	11	D35M210/P1/11	CASQUILLO CULATA MOTOR DUCATI 210CC DCW/DHL
P1	12	D35M210/P1/12	TORNILLO CULATA MOTOR DUCATI 210CC DCW/DHL
P1	13	D35M210/P1/13	BUJIA MOTOR DUCATI 210CC DCW/DHL
P1	14	D35M210/P1/14	CULATA COMPLETA MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS



P2


PAG	POS	REFERENCIA	DESCRIPCION
P2	1	D35M210/P2/1	CILINDRO MOTOR DUCATI 210CC DCW/DHL
P2	2	D35M210/P2/2	ALARMA ACEITE MOTOR DUCATI 210CC DCW/DHL
P2	3	D35M210/P2/3	REGULADOR COMPLETO MOTOR DUCATI 210CC DCW/DHL
P2	7	D35M210/P2/7	EJE REGULADOR MOTOR DUCATI 210CC DCW/DHL
P2	8	D35M210/P2/8	TORNILLO VACIADO CARTER MOTOR DUCATI 210CC DCW/DHL
P2	9	D35M210/P2/9	ARANDELA TORNILLO VACIADO MOTOR DUCATI 210CC DCW/DHL
P2	12	D35M210/P2/12	RODAMIENTO CIGÜEÑAL MOTOR DUCATI 210CC DCW/DHL
P2	13	D35M210/P2/13	RETEN CIGÜEÑAL MOTOR DUCATI 210CC DCW/DHL
P2	15	D35M210/P2/15	TUERCA ALARMA MOTOR DUCATI 210CC DCW/DHL
P2	16	D35M210/P2/16	ARANDELA MOTOR DUCATI 210CC DCW/DHL
P2	17	D35M210/P2/17	PASADOR MOTOR DUCATI 210CC DCW/DHL
P2	18	D35M210/P2/18	TORNILLO ALARMA MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS

P3




PAG	POS	REFERENCIA	DESCRIPCION
P3	1	D35M210/P3/1	TAPA CARTER MOTOR DUCATI 210CC DCW/DHL
P3	2	D35M210/P3/2	RODAMIENTO CIGÜEÑAL MOTOR DUCATI 210CC DCW/DHL
P3	3	D35M210/P3/3	RETEN CIGÜEÑAL MOTOR DUCATI 210CC DCW/DHL
P3	4	D35M210/P3/4	JUNTA TAPA CARTER MOTOR DUCATI 210CC DCW/DHL
P3	5	D35M210/P3/5	CASQUILLO TAPA CARTER MOTOR DUCATI 210CC DCW/DHL
P3	6	D35M210/P3/6	TAPON VARILLA NIVEL ACEITE MOTOR DUCATI 210CC DCW/DHL
P3	8	D35M210/P3/8	TAPON ACEITE MOTOR DUCATI 210CC DCW/DHL
P3	9	D35M210/P3/9	TORNILLO TAPA CARTER MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P4

PAG	POS	REFERENCIA	DESCRIPCION
P4	1	D35M210C/P4/1	CIGÜEÑAL MOTOBOMBA DCW DUCATI 210CC DCW
P4	1	D35M210H/P4/1	CIGÜEÑAL MOTOBOMBA DHL DUCATI 210CC DHL/DDW
P4	1	D35M210CH/P4/1	CIGÜEÑAL MOTOBOMBA DHL DUCATI 210CC DCH

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P5

PAG	POS	REFERENCIA	DESCRIPCION
P5	1	D35M210/P5/1	KIT SEGMENTOS MOTOR DUCATI 210CC DCW/DHL
P5	2	D35M210/P5/2	GRUPILLA BULON MOTOR DUCATI 210CC DCW/DHL
P5	3	D35M210/P5/3	PISTON MOTOR DUCATI 210CC DCW/DHL
P5	4	D35M210/P5/4	BULON MOTOR DUCATI 210CC DCW/DHL
P5	5	D35M210/P5/5	BIELA MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS



P6


PAG	POS	REFERENCIA	DESCRIPCION
P6	1	D35M210/P6/1	ARBOL DE LEVAS MOTOR DUCATI 210CC DCW/DHL
P6	2	D35M210/P6/2	KIT VALVULAS MOTOR DUCATI 210CC DCW/DHL
P6	3	D35M210/P6/3	PLATILLO VALVULAS MOTOR DUCATI 210CC DCW/DHL
P6	4	D35M210/P6/4	PLATILLO VALVULAS MOTOR DUCATI 210CC DCW/DHL
P6	5	D35M210/P6/5	CASQUILLO VALVULA MOTOR DUCATI 210CC DCW/DHL
P6	6	D35M210/P6/6	ASIENTO MUELLE MOTOR DUCATI 210CC DCW/DHL
P6	7	D35M210/P6/7	TAQUE MOTOR DUCATI 210CC DCW/DHL
P6	8	D35M210/P6/8	VARILLA EMPUJADORA MOTOR DUCATI 210CC DCW/DHL
P6	9	D35M210/P6/9	GUIA VARILLA EMPUJADORA MOTOR DUCATI 210CC DCW/DHL
P6	10	D35M210/P6/10	ESPARRAGO AJUSTE BALANCINES MOTOR DUCATI 210CC DCW/DHL
P6	11	D35M210/P6/11	BALANCINES MOTOR DUCATI 210CC DCW/DHL
P6	12	D35M210/P6/12	TUERCA AJUSTE BALANCIN MOTOR DUCATI 210CC DCW/DHL
P6	13	D35M210/P6/13	CONTRATUERCA AJUSTE MOTOR DUCATI 210CC DCW/DHL
P6	14	D35M210/P6/14	MUELLE VALVULAS MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS

P7




PAG	POS	REFERENCIA	DESCRIPCION
P7	11	D35M210/P7/11	TORNILLO ARRANCADOR MOTOR DUCATI 210CC DCW/DHL
P7	12	D35M210/P7/12	ARRANADOR COMPLETO MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P8

PAG	POS	REFERENCIA	DESCRIPCION
P8	1	D35M210/P8/1	CARCASA AIREACION MOTOR DUCATI 210CC DCW/DHL
P8	2	D35M210/P8/2	CHAPA AIREACION CULATA MOTOR DUCATI 210CC DCW/DHL
P8	3	D35M210/P8/3	CHAPA VOLANTE MOTOR DUCATI 210CC DCW/DHL
P8	4	D35M210/P8/4	DIODO MOTOR DUCATI 210CC DCW/DHL
P8	5	D35M210/P8/5	INTERRUPTOR ON/OFF MOTOR DUCATI 210CC DCW/DHL
P8	6	D35M210/P8/6	TORNILLO MOTOR DUCATI 210CC DCW/DHL
P8	7	D35M210/P8/7	TORNILLO MOTOR DUCATI 210CC DCW/DHL
P8	8	D35M210/P8/8	SUJETA CABLE MOTOR DUCATI 210CC DCW/DHL
P8	9	D35M210/P8/9	TORNILLO MOTOR DUCATI 210CC DCW/DHL
P8	10	D35M210/P8/10	TORNILLO MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P9

PAG	POS	REFERENCIA	DESCRIPCION
P9	1	D35M210/P9/1	CARBURADOR MOTOR DUCATI 210CC DCW/DHL
P9	2	D35M210/P9/2	JUNTA FILTRO DE AIRE MOTOR DUCATI 210CC DCW/DHL
P9	3	D35M210/P9/3	JUNTA CARBURADOR MOTOR DUCATI 210CC DCW/DHL
P9	33	D35M210/P9/33	SEPARADOR TERMICO MOTOR DUCATI 210CC DCW/DHL
P9	34	D35M210/P9/34	JUNTA ADMISION MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P10

PAG	POS	REFERENCIA	DESCRIPCION
P10	1	D35M210/P10/1	ANCLAJE FILTRO DE AIRE COMPLETO MOTOR DUCATI 210CC DCW/DHL
P10	2	D35M210/P10/2	TUERCA MOTOR DUCATI 210CC DCW/DHL
P10	3	D35M210/P10/3	ELEMENTO FILTRO AIRE SECO 210 DCW/DHL
P10	4	D35M210/P10/1A	ANCLAJE FILTRO AIRE BAÑO ACEITE 210CC DCW/DHL
P10	5	D35M210/P10/2A	ELEMENTO FILTRO AIRE BAÑO ACEITE 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P11

PAG	POS	REFERENCIA	DESCRIPCION
P11	1	D35M210/P11/1	JUNTA SILENCIOSO MOTOR DUCATI 210CC DCW/DHL
P11	2	D35M210/P11/2	TUERCA MOTOR DUCATI 210CC DCW/DHL
P11	3	D35M210/P11/3	SILENCIOSO COMPLETO MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P12

PAG	POS	REFERENCIA	DESCRIPCION
P12	1	D35M210/P12/1	DEPOSITO COMBUSTIBLE MOTOR 210CC DCW/DHL
P12	2	D35M210/P12/2	FILTRO LLENADO COMBUSTIBLE MOTOR 210CC DCW/DHL
P12	3	D35M210/P12/3	TAPON DEPOSITO COMBUSTIBLE MOTOR 210CC DCW/DHL
P12	4	D35M210/P12/4	FILTRO SALIDA COMBUSITBLE MOTOR 210CC DCW/DHL
P12	5	D35M210/P12/5	CLIP MOTOR 210CC DCW/DHL
P12	6	D35M210/P12/6	TUBO COMBUSTIBLE MOTOR 210CC DCW/DHL
P12	7	D35M210/P12/7	TORNILLO MOTOR 210CC DCW/DHL
P12	8	D35M210/P12/8	TUERCA MOTOR 210CC DCW/DHL
P12	9	D35M210/P12/9	TUBO PROTECTOR MOTOR 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS




P13

PAG	POS	REFERENCIA	DESCRIPCION
P13	1	D35M210/P13/1	TUERCA VOLANTE MOTOR DUCATI 210CC DCW/DHL
P13	2	D35M210/P13/2	POLEA ARRANCADORA MOTOR DUCATI 210CC DCW/DHL
P13	3	D35M210/P13/3	VENTILADOR MOTOR DUCATI 210CC DCW/DHL
P13	4	D35M210/P13/4	VOLANTE MAGNETICO MOTOR DUCATI 210CC DCW/DHL
P13	7	D35M210/P13/7	TORNILLO BOBINA MOTOR DUCATI 210CC DCW/DHL
P13	9	D35M210/P13/9	BOBINA DE ARRANQUE MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOR 210CC MOTOBOMBAS



P14


PAG	POS	REFERENCIA	DESCRIPCION
P14	1	D35M210/P14/1	ACELERADOR COMPLETO MOTOR DUCATI 210CC DCW/DHL
P14	11	D35M210/P14/11	TORNILLO MOTOR DUCATI 210CC DCW/DHL
P14	12	D35M210/P14/12	MUELLE REGULADOR MOTOR DUCATI 210CC DCW/DHL
P14	13	D35M210/P14/13	VARILLA ACELERADOR MOTOR DUCATI 210CC DCW/DHL
P14	14	D35M210/P14/14	MUELLE RETORNO MOTOR DUCATI 210CC DCW/DHL
P14	15	D35M210/P14/15	TORNILLO REGULADOR MOTOR DUCATI 210CC DCW/DHL
P14	16	D35M210/P14/16	TUERCA MOTOR DUCATI 210CC DCW/DHL
P14	17	D35M210/P14/17	BRAZO REGULADOR MOTOR DUCATI 210CC DCW/DHL

VERSION 1.0



MOTOBOMBA ACIDO DCH50 REF: DCH3550

P15



VERSION 1.0



MOTOBOMBA ACIDO DCH50 REF: DCH3550


PAG	POS	REFERENCIA	DESCRIPCION
P15	1	DCH3550/P15/1	TUERCA DCH50
P15	2	DCH3550/P15/2	ARANDELA DCH50
P15	3	DCH3550/P15/3	ARANDELA DCH50
P15	4	DCH3550/P15/4	TAPA TRASERA BOMBA DCH50
P15	5	DCH3550/P15/5	ARANDELA DCH50
P15	6	DCH3550/P15/6	ARANDELA DCH50
P15	7	DCH3550/P15/7	TORNILLO DCH50
P15	11	DCH3550/P15/11	SELLO MECANICO COMPLETO DCH50
P15	12	DCH3550/P15/12	TURBINA DCH50
P15	13	DCH3550/P15/13	ARANDELA DCH50
P15	14	DCH3550/P15/14	ARANDELA DCH50
P15	15	DCH3550/P15/15	ARANDELA DCH50
P15	16	DCH3550/P15/16	TORNILLO TURBINA DCH50
P15	17	DCH3550/P15/17	DIFUSOR DCH50
P15	18	DCH3550/P15/18	TORNILLO DCH50
P15	19	DCH3550/P15/19	JUNTA DIFUSOR DCH50
P15	20	DCH3550/P15/20	ANILLO TORICO CUERPO BOMBA DCH50

PAG	POS	REFERENCIA	DESCRIPCION
P15	21	DCH3550/P15/21	JUNTA TORICA TAPON LLENADO VACIADO DCH50
P15	22	DCH3550/P15/22	TAPON LLENADO/ VACIADO DCH50
P15	23	DCH3550/P15/23	CUERPO BOMBA PRINCIPAL DCH50
P15	24	DCH3550/P15/24	TORINILLO DCH50
P15	25	DCH3550/P15/25	RACOR SALIDA DCH50
P15	26	DCH3550/P15/26	CODO SALIDA DCH50
P15	27	DCH3550/P15/27	JUNTA RACOR SALIDA DCH50
P15	28	DCH3550/P15/28	JUNTA CODO SALIDA DCH50
P15	29	DCH3550/P15/29	ESPIGA RACOR ASPIRACION/IMPULSION DCH50
P15	30	DCH3550/P15/30	JUNTA PLANA RACOR ASPIRACION/IMPULSION DCH50
P15	31	DCH3550/P15/31	TUERCA RACOR ASPIRACION/IMPULSION DCH50
P15	32	DCH3550/P15/32	ABRAZADERA DCH50
P15	33	DCH3550/P15/33	TORNILLO DCH50
P15	34	DCH3550/P15/34	TAPA FILTRO ASPIRACION DCH50
P15	35	DCH3550/P15/35	FILTRO ASPIRACION DCH50
P15	36	DCH3550/P15/36	KIT BOMBA COMPLETO ACIDO DCH50



MOTOBOMBA ACIDO DCH50 REF: DCH3550

P16



PAG	POS	REFERENCIA	DESCRIPCION
P16	1	DCH3550/P16/1	CHASIS DCH50
P16	2	DCH3550/P16/2	TORNILLO DCH50
P16	3	DCH3550/P16/3	PATA GOMA DCH50
P16	4	DCH3550/P16/4	TORNILLO DCH50
P16	5	DCH3550/P16/5	TUERCA DCH50

VERSION 1.0