




CORTACESPED DUCATI DLM5101T

P1






# CORTACESPED DUCATI DLM5101T

PAG	POS	REFERENCIA	DESCRIPCION	CANT	PAG	POS	REFERENCIA	DESCRIPCION	CANT
P1	1	DLM4601/1	TORNILLO CUCHILLA DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	26	DLM5101T/26	MANILLAR SUPERIOR DLM5101T	1
P1	2	DLM4601/2	ARANDELA DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	27	DLM4601/42	TORNILLO DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	3	DLM4601/30	GRUPILLA DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	28	DLM4601/43	PALANCA FRENO MOTOR DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	4	DLM5101T/4	CUCHILLA DLM5101T	1	P1	29	DLM4601/25	ESPUMA MANILLAR DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	5	DLM4601/5	PORTACUCHILLAS DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	30	DLM5101T/30	CABLE PARE DLM5101T	1
P1	6	DLM5101T/6	RESORTE ELEVACION DLM5101T	1	P1	31	DLM4601/48	TUERCA 6 DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	2
P1	7	DLM5101T/7	GRUPILLA 6 DLM5101T	1	P1	32	DLM4601/46	TUERCA DLM4601DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	8	DLM5101T/8	PLATO DE CORTE DLM5101T	1	P1	33	DLM4601/45	GUIA CUERDA ARRANQUE DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	9	DLM4601/10	TUERCA 6 DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4	P1	34	DLM4601/27	TUERCA 8 DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4
P1	10	DLM5101T/10	PRESILLA SOPORTE EJE DLM5101T	2	P1	35	DLM5101T/35	SOPORTE REGULACION DRCH DLM5101T	1
P1	11	DLM5101T/11	TORNILLO 6*16 DLM5101T/DLM5301P/DLM5301/DLM5301E	2	P1	36	DLM5101T/36	PALANCA ELEVACION DLM5101T	1
P1	12	DLM4601/35	TORNILLO 8*16 DLM4601/DLM5101T	4	P1	37	DLM5101T/37	EJE TAPA LATERAL DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	13	DLM5101T/13	SOPORTE REGULACION IZQ DLM5101T	1	P1	38	DLM5101T/38	RESORTE TAPA LATERAL DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	14	DLM4601/19	TORNILLO DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	3	P1	39	DLM5101T/39	SOPORTE TAPA LATERAL DLM5101T/DLM5301P/DLM5301/DLM5301E	1
P1	15	DLM4601/20	TORNILLO 6*12 DLM4601/DLM5101T	4	P1	40	DLM5101T/40	TAPA SALIDA LATERAL DLM5101T	1
P1	16	DLM4601/70	ARANDELA DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4	P1	41	DLM5101T/41	TOBERA SALIDA LATERAL DLM5101T	1
P1	17	DLM4601/22	MOTOR REPUESTO DLM4601/DLM5101T	1	P1	42	DLM5101T/42	TUERCA 10 DLM5101T	4
P1	18	DLM5101T/18	PLACA DLM5101T	2	P1	43	DLM5101T/43	RUEDA DELANTERA DLM5101T	2
P1	19	DLM4601/29	TAPON DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	2	P1	44	DLM5101T/44	TORNILLO BARRA UNION DLM5101T/DLM5301P/DLM5301/DLM5301E	2
P1	20	DLM4601/72	RESORTE ELEVACION DLM4601/DLM5101T	1	P1	45	DLM5101T/45	EJE DELANTERO DLM5101T	1
P1	21	DLM4601/37	POMO MANILLAR DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4	P1	46	DLM4601/59	ARANDELA DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4
P1	22	DLM4601/28	TORNILLO DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	4	P1	47	DLM5101T/47	RUEDA TRASERA DLM5101T	2
P1	23	DLM4601/39	CLIP CABLES DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	48	DLM5101T/48	EJE TRASERO DLM5101T	1
P1	24	DLM5101T/24	MANILLAR INFERIOR DLM5101T/DLM5301P/DLM5301/DLM5301E	1	P1	49	DLM4601/69	TUERCA 6 DLM4601/DLM5101T/DLM5301P/DLM5301/DLM5301E	2
P1	25	DLM5101T/25	BARRA UNION DEL-TRAS DLM5101T	1	P1	50	DLM5101T/50	ARANDELA DLM5101T/DLM5301P/DLM5301/DLM5301E	2



# CORTACESPED DUCATI DLM5101T

P2



VERSION 3.0



# CORTACESPED DUCATI DLM5101T

PAG	POS	REFERENCIA	DESCRIPCION	CANT	PAG	POS	REFERENCIA	DESCRIPCION	CANT
P2	1	DLM4601M/1	CILINDRO DLM4601/DLM5101T	1	P2	42	DLM4601M/42	ARANDELA AJUSTE CIGÜEÑAL DLM4601/DLM5101T/DLM5301P/DLM5301	1
P2	2	DLM4601M/2	EJE REGULADOR DLM4601/DLM5101T/DLM5301P	1	P2	43	DLM4601M/43	CENTRADOR TAPA CARTER DLM4601/DLM5101T/DLM5301P	2
P2	3	DLM4601M/3	RETEN EJE REGULADOR DLM4601/DLM5101T/DLM5301P	1	P2	44	DLM4601M/44	JUNTA CULATA DLM4601/DLM5101T	1
P2	4	DLM4601M/4	BOBINA DE ARRANQUE DLM4601/DLM5101T/DLM5301P	1	P2	45	DLM4601M/45	CULATA DLM4601/DLM5101T	1
P2	5	DLM4601M/5	VOLANTE DE ARRANQUE DLM4601/DLM5101T/DLM5301P	1	P2	46	DLM4601M/46	RETEN CIGÜEÑAL TAPA DLM4601/DLM5101T/DLM5301P	1
P2	6	DLM4601M/6	VENTILADOR DLM4601/DLM5101T	1	P2	47	DLM4601M/47	RETEN CIGÜEÑAL VENTILADOR DLM4601/DLM5101T/DLM5301P	1
P2	7	DLM4601M/7	PLACA SUJECCION VENTILADOR DLM4601/DLM5101T/DLM5301P	1	P2	48	DLM4601M/48	PIÑON DISTRIBUCION CIGÜEÑAL DLM4601/DLM5101T/DLM5301P	1
P2	8	DLM4601M/8	TUBO RESPIRADERO DLM4601/DLM5101T/DLM5301P	1	P2	49	DLM4601M/49	TUBO COMBUSTIBLE DLM4601/DLM5101T/DLM5301P	1
P2	9	DLM4601M/9	TAPA VALVULAS DLM4601/DLM5101T/DLM5301P	1	P2	50	DLM4601M/50	CLIP TUBO DLM4601/DLM5101T/DLM5301P	1
P2	10	DLM4601M/10	TAPA RESPIRADERO DLM4601/DLM5101T/DLM5301P	1	P2	51	DLM4601M/51	MUELLE REGULADOR DLM4601/DLM5101T/DLM5301P	1
P2	11	DLM4601M/11	TORNILLO 4*6 DLM4601/DLM5101T/DLM5301P	1	P2	52	DLM4601M/52	BRAZO REGULADOR DLM4601/DLM5101T/DLM5301P	1
P2	12	DLM4601M/12	TAPA CARTER DLM4601/DLM5101T/DLM5301P	1	P2	53	DLM4601M/53	FRENO MOTOR DLM4601/DLM5101T/DLM5301P	1
P2	13	DLM4601M/13	SEPARADOR TERMICO DLM4601/DLM5101T/DLM5301P	1	P2	54	DLM4601M/54	MUELLE FRENO MOTOR DLM4601/DLM5101T/DLM5301P	1
P2	14	DLM4601M/14	CABURADOR DLM4601/DLM5101T	1	P2	55	DLM4601M/55	CABLE PARE DLM4601/DLM5101T/DLM5301P	1
P2	15	DLM4601M/15	TAPA RESPIRADERO DLM4601/DLM5101T/DLM5301P	1	P2	56	DLM4601M/56	SOPORTE CABLE FRENO DLM4601/DLM5101T/DLM5301P	1
P2	16	DLM4601M/16	PISTON DLM4601/DLM5101T	1	P2	57	DLM4601M/57	ARBOL DE LEVAS DLM4601/DLM5101T	1
P2	17	DLM4601M/17	JUEGO SEGMENTOS DLM4601/DLM5101T	1	P2	58	DLM4601M/58	SILENCIOSO DLM4601/DLM5101T/DLM5301P	1
P2	18	DLM4601M/18	BULON PISTON DLM4601/DLM5101T/DLM5301P	1	P2	59	DLM4601M/59	BALANCINES DLM4601/DLM5101T/DLM5301P	2
P2	19	DLM4601M/19	CLIP BULON DLM4601/DLM5101T/DLM5301P	2	P2	60	DLM4601M/60	VARILLA ACELERADOR DLM4601/DLM5101T/DLM5301P	1
P2	20	DLM4601M/20	BUJIA DLM4601/DLM5101T/DLM5301P	1	P2	61	DLM4601M/61	DEPOSITO COMBUSTIBLE DLM4601/DLM5101T/DLM5301P	1
P2	21	DLM4601M/21	VARILLA NIVEL ACEITE DLM4601/DLM5101T/DLM5301P	1	P2	62	DLM4601M/62	TAPON DEPOSITO COMBUSTIBLE DLM4601/DLM5101T/DLM5301P/DLM5301P	1
P2	22	DLM4601M/22	TUBO VARILLA NIVEL DLM4601/DLM5101T/DLM5301P	1	P2	63	DLM4601M/63	CLIP EJE REGULADOR DLM4601/DLM5101T/DLM5301P	1
P2	23	DLM4601M/23	VALVULA ADMISION DLM4601/DLM5101T/DLM5301P	1	P2	64	DLM4601M/64	PASADOR BALANCINES DLM4601/DLM5101T/DLM5301P	1
P2	24	DLM4601M/24	ASIEN TO RETEN DLM4601/DLM5101T/DLM5301P	2	P2	65	DLM4601M/65	CHAPA VENTILACION 1 DLM4601/DLM5101T/DLM5301P	1
P2	25	DLM4601M/25	PLATILLO VALVULA ADMISION DLM4601/DLM5101T/DLM5301P/DLM5301P	2	P2	66	DLM4601M/66	CHAPA VENTILACION 2 DLM4601/DLM5101T/DLM5301P	1
P2	26	DLM4601M/26	ANCLAJE FILTRO AIRE DLM4601/DLM5101T/DLM5301P	1	P2	67	DLM4601M/67	EMBELLECEDOR MOTOR DLM4601/DLM5101T/DLM5301P	1
P2	26P	DLM4601M/26P	CEBADOR DLM4601/DLM5101T/DLM5301P		P2	68	DLM4601M/68	ARRANCADOR COMPLETO DLM4601/DLM5101T	1
P2	27	DLM4601M/27	PIÑON REGULADOR DLM4601/DLM5101T/DLM5301P	1	P2	69	DLM4601M/69	TORNILLO 4.2*16 DLM4601/DLM5101T/DLM5301P	3
P2	28	DLM4601M/28	BIELA DLM4601/DLM5101T/DLM5301P	1	P2	70	DLM4601M/70	JUNTA SILENCIOSO DLM4601/DLM5101T/DLM5301P	1
P2	29	DLM4601M/29	TUERCA VOLANTE DLM4601/DLM5101T/DLM5301P	1	P2	71	DLM4601M/71	TORNILLO 6*10 DLM4601/DLM5101T/DLM5301P	4
P2	30	DLM4601M/30	TORNILLO 6*16 DLM4601/DLM5101T/DLM5301P	10	P2	72	DLM4601M/72	ARANDELA DLM4601/DLM5101T/DLM5301P	1
P2	31	DLM4601M/31	TORNILLO 6*25 DLM4601/DLM5101T/DLM5301P	9	P2	73	DLM4601M/73	TUERCA M6 DLM4601/DLM5101T/DLM5301P/DLM5301	4
P2	32	DLM4601M/32	TORNILLO 8*45 DLM4601/DLM5101T/DLM5301P	4	P2	74	DLM4601M/74	TUBO SOBREADERO DLM4601/DLM5101T/DLM5301P	1
P2	33	DLM4601M/33	ESPARRAGO 6*92 DLM4601/DLM5101T/DLM5301P	2	P2	75	DLM4601M/75	ESPARRAGO SILENCIOSO DLM4601/DLM5101T/DLM5301P	2
P2	34	DLM4601M/34	JUNTA FILTRO AIRE DLM4601/DLM5101T/DLM5301P/DLM5301	1	P2	76	DLM4601M/76	CLIP TUBO DLM4601/DLM5101T/DLM5301P	1
P2	35	DLM4601M/35	JUNTA ADMISION DLM4601/DLM5101T/DLM5301P	1	P2	77	DLM4601M/77	REJILLA SILENCIOSO DLM4601/DLM5101T/DLM5301P	1
P2	36	DLM4601M/36	JUNTA CARBURADOR DLM4601/DLM5101T/DLM5301P	1	P2	78	DLM4601M/78	TORNILLO 6*22 DLM4601/DLM5101T/DLM5301P	1
P2	37	DLM4601M/37	VALVULA ESCAPE DLM4601/DLM5101T/DLM5301P	1	P2	79	DLM4601M/79	FILTRO COMBUSTIBLE DLM4601/DLM5101T/DLM5301P	1
P2	38	DLM4601M/38	MUELLE VALVULA DLM4601/DLM5101T/DLM5301P	2	P2	80	DLM4601M/80	ELEMENTO FILTRO AIRE DLM4601/DLM5101T/DLM5301P	1
P2	39	DLM4601M/39	TAQUE DLM4601/DLM5101T/DLM5301P	2	P2	81	DLM4601M/81	JUNTA TAPA VALVULAS DLM4601/DLM5101T/DLM5301P	1
P2	40	DLM4601M/40	VARILLA EMPUJADORA DLM4601/DLM5101T/DLM5301P	2	P2	82	DLM5301M/98	CHAVETA VOLANTE ARRANQUE DLM5301P-DLM5101T-DLM5301	1
P2	41	DLM4601M/41	CIGÜEÑAL DLM4601/DLM5101T/DLM5301P	1					