




MOTOR 390 TIPO Q REF. DPE125390Q


P1



PAG	POS	REF.MIRAL	DESCRIPCION
P1	5	D35M390/P1/5	JUNTA CULATA MOTOR DUCATI 390CC
P1	6	D35M390/P1/6	TAPA VALVULAS MOTOR DUCATI 390CC
P1	7	D35M390/P1/7	JUNTA TAPA VALVULAS MOTOR DUCATI 390CC
P1	8	D35M390/P1/8	TUBO RESPIRADERO MOTOR DUCATI 390CC
P1	9	D35M390/P1/9	TORNILLO TAPA VALVULAS MOTOR DUCATI 390CC
P1	10	D35M390/P1/10	ARANDELA TORNILLO TAPA MOTOR DUCATI 390CC
P1	11	D35M390/P1/11	JUNTA TORNILLO TAPA MOTOR DUCATI 390CC
P1	12	D35M390/P1/12	ESPARRAGO CARBURADOR MOTOR DUCATI 390CC
P1	13	D35M390/P1/13	ESPARRAGO ESCAPE MOTOR DUCATI 390CC
P1	14	D35M390/P1/14	CASQUILLO CULATA MOTOR DUCATI 390CC
P1	15	D35M390/P1/15	TORNILLO CULATA MOTOR DUCATI 390CC
P1	16	CTR7F	BUJIA MOTOR OHV - CORTACESPED
P1	17	D35M390/P1/17	CULATA COMPLETA MOTOR DUCATI 390CC



MOTOR 390 TIPO Q REF. DPE125390Q




P2

PAG	POS	REF.MIRAL	DESCRIPCION
P2	1	D35M390/P2/1	CILINDRO MOTOR DUCATI 390CC
P2	2	D35M390/P2/2	RETEN LADO VOLANTE MOTOR DUCATI 390CC
P2	3	D35M390/P2/3	ALARMA NIVEL ACEITE MOTOR DUCATI 390CC
P2	4	D35M390/P2/4	GOMA PASACABLE MOTOR DUCATI 390CC
P2	5	D35M390/P2/5	DIODO MOTOR DUCATI 390CC
P2	6	D35M390/P2/6	TORNILLO MOTOR DUCATI 390CC
P2	7	D35M390/P2/7	ARANDELA VACIADO CARTER MOTOR DUCATI 390CC
P2	8	D35M390/P2/8	TORNILLO VACIADO CARTER MOTOR DUCATI 390CC
P2	9	D35M390/P2/9	SUJETA CABLES MOTOR DUCATI 390CC
P2	10	D35M390/P2/10	EJE BRAZO REGULADOR MOTOR DUCATI 390CC
P2	11	D35M390/P2/11	ARANDELA MOTOR DUCATI 390CC
P2	12	D35M390/P2/12	PASADOR MOTOR DUCATI 390CC
P2	13	D35M390/P2/13	TUERCA MOTOR DUCATI 390CC
P2	14	D35M390/P2/14	TORNILLO MOTOR DUCATI 390CC
P2	15	D35M390/P2/15	RODAMIENTO MOTOR DUCATI 390CC
P2	16	D35M390/P2/16	RETEN MOTOR DUCATI 390CC



MOTOR 390 TIPO Q REF. DPE125390Q


P3




PAG	POS	REF.MIRAL	DESCRIPCION
P3	1	D35M390/P3/1	TAPA CARTER MOTOR DUCATI 390CC
P3	2	D35M390/P3/2	JUNTA TAPA CARTER MOTOR DUCATI 390CC
P3	3	D35M390/P3/3	TAPON ACEITE MOTOR DUCATI 390CC
P3	4	D35M390/P3/4	TAPON VARILLA NIVEL ACEITE MOTOR DUCATI 390CC
P3	5	D35M390/P3/5	CASQUILLO MOTOR DUCATI 390CC
P3	6	D35M390/P3/6	TORNILLO MOTOR DUCATI 390CC
P3	7	D35M390/P3/7	RODAMIENTO CIGÜEÑAL MOTOR DUCATI 390CC
P3	8	D35M390/P3/8	RODAMIENTO ARBOL DE LEVAS MOTOR DUCATI 390CC
P3	9	D35M390/P3/9	PIÑON REGULADOR MOTOR DUCATI 390CC
P3	10	D35M390/P3/10	RETEN CARTER MOTOR DUCATI 390CC



MOTOR 390 TIPO Q REF. DPE125390Q



PAG	POS	REF.MIRAL	DESCRIPCION
P4	1	DPE125390Q/C	CIGÜEÑAL Q MOTOR DUCATI 390CC
P4	2	D35M390/P4/2	CONTRAPEO MOTOR DUCATI 390CC




PAG	POS	REF.MIRAL	DESCRIPCION
P5	2	D35M390/P5/2	PISTON MOTOR DUCATI 390CC
P5	3	D35M390/P5/3	BULON MOTOR DUCATI 390CC
P5	4	D35M390/P5/4	CLIP PISTON MOTOR DUCATI 390CC
P5	5	D35M390/P5/5	BIELA MOTOR DUCATI 390CC
P5	7	D35M390/P5/7	SEGMENTO 1 MOTOR DUCATI 390CC
P5	8	D35M390/P5/8	SEGMENTO 2 MOTOR DUCATI 390CC
P5	9	D35M390/P5/9	SEGMENTO 3 MOTOR DUCATI 390CC




MOTOR 390 TIPO Q REF. DPE125390Q

P6



PAG	POS	REF.MIRAL	DESCRIPCION
P6	1	D35M390/P6/1	ARBOL DE LEVAS COMPLETO MOTOR DUCATI 390CC
P6	3	D35M390/P6/3	VALVULA ADMISION MOTOR DUCATI 390CC
P6	4	D35M390/P6/4	VALVULA ESCAPE MOTOR DUCATI 390CC
P6	5	D35M390/P6/5	MUELLE VALVULA MOTOR DUCATI 390CC
P6	6	D35M390/P6/6	PLATILLO VALVULA ADMISION MOTOR DUCATI 390CC
P6	7	D35M390/P6/7	CASQUILLO VALVULA MOTOR DUCATI 390CC
P6	8	D35M390/P6/8	RETEN VALVULA ESCAPE MOTOR DUCATI 390CC
P6	9	D35M390/P6/9	PLATILLO VALVULA ESCAPE MOTOR DUCATI 390CC
P6	10	D35M390/P6/10	TAQUE MOTOR DUCATI 390CC
P6	11	D35M390/P6/11	VARILLA EMPUJADORA MOTOR DUCATI 390CC
P6	12	D35M390/P6/12	CHAPA GUIA VALVULA MOTOR DUCATI 390CC
P6	13	D35M390/P6/13	ESPARRAGO REGULACION BALANCIN MOTOR DUCATI 390CC
P6	14	D35M390/P6/14	BALANCIN MOTOR DUCATI 390CC
P6	15	D35M390/P6/15	TUERCA BALANCIN MOTOR DUCATI 390CC
P6	16	D35M390/P6/16	CONTRATUERCA MOTOR DUCATI 390CC
P6	17	D35M390/P6/17	ASIENTO MUELLE MOTOR DUCATI 390CC




P7

PAG	POS	REF.MIRAL	DESCRIPCION
p7	12	D35M390/P7/12	ARRANCADOR COMPLETO MOTOR DUCATI 390CC
p7	13	D35M390/P7/13	TORNILLO MOTOR DUCATI 390CC

PAG	POS	REF.MIRAL	DESCRIPCION
P8	1	D35M390/P8/1	CARCASA AIREACION MOTOR DUCATI 390CC
P8	2	D35M390/P8/2	CHAPA AIREACION CULATA MOTOR DUCATI 390CC
P8	3	D35M390/P8/3	TORNILLO MOTOR DUCATI 390CC
P8	4	D35M390/P8/4	INTERRUPTOR ON/OFF MOTOR DUCATI 390CC
P8	5	D35M390/P8/5	TORNILLO MOTOR DUCATI 390CC
P8	8	D35M390/P8/8	CLIP TUBO MOTOR DUCATI 390CC


VERSION 1.0



P9

MOTOR 390 TIPO Q REF. DPE125390Q

PAG	POS	REF.MIRAL	DESCRIPCION
P9	1	D35M390/P9/1	CARBURADOR MOTOR DUCATI 390CC
P9	2	D35M390/P9/2	JUNTA FILTRO AIRE MOTOR DUCATI 390CC
P9	3	D35M390/P9/3	JUNTA CARBURADOR MOTOR DUCATI 390CC
P9	33	D35M390/P9/33	SEPARADOR TERMICO MOTOR DUCATI 390CC
P9	34	D35M390/P9/34	JUNTA ADMISION MOTOR DUCATI 390CC




P10

PAG	POS	REF.MIRAL	DESCRIPCION
P10	1	D35M390/P10/1	ANCLAJE FILTRO DE AIRE MOTOR DUCATI 390CC
P10	4	D35M390/P10/4	TUERCA MOTOR DUCATI 390CC




MOTOR 390 TIPO Q REF. DPE125390Q



P11

PAG	POS	REF.MIRAL	DESCRIPCION
P11	4	D35M390/P11/4	JUNTA COLECTOR MOTOR DUCATI 390CC
P11	5	D35M390/P11/5	COLECTOR MOTOR DUCATI 390CC
P11	6	D35M390/P11/6	JUNTA SILENCIOSO MOTOR DUCATI 390CC
P11	7	D35M390/P11/7	TUERCA MOTOR DUCATI 390CC
P11	8	D35M390/P11/8	TUERCA MOTOR DUCATI 390CC
P11	9	D35M390/P11/9	SILENCIOSO COMPLETO MOTOR DUCATI 390CC




P12

PAG	POS	REF.MIRAL	DESCRIPCION
P12	1	D35M390/P12/1	DEPOSITO COMBUSTIBLE MOTOR DUCATI 390CC
P12	2	D35M390/P12/2	FILTRO LLENADO COMBUSTIBLE MOTOR DUCATI 390CC
P12	3	D35M390/P12/3	TAPON DEPOSITO COMBUSTIBLE MOTOR DUCATI 390CC
P12	4	D35M390/P12/4	FILTRO SALIDA COMBUSTIBLE MOTOR DUCATI 390CC
P12	5	D35M390/P12/5	CLIP COMBUSTIBLE MOTOR DUCATI 390CC
P12	6	D35M390/P12/6	TUBO COMBUSTIBLE MOTOR DUCATI 390CC
P12	7	D35M390/P12/7	TORNILLO COMBUSTIBLE MOTOR DUCATI 390CC
P12	8	D35M390/P12/8	TUERCA COMBUSTIBLE MOTOR DUCATI 390CC
P12	9	D35M390/P12/9	CLIP TUBO COMBUSTIBLE MOTOR DUCATI 390CC




P13

MOTOR 390 TIPO Q REF. DPE125390Q



PAG	POS	REF.MIRAL	DESCRIPCION
P13	1	D35M390/P13/1	TUERCA MOTOR DUCATI 390CC
P13	2	D35M390/P13/2	POLEA ARRANCADORA MOTOR DUCATI 390CC
P13	3	D35M390/P13/3	VELTILADOR MOTOR DUCATI 390CC
P13	4	D35M390/P13/4	VOLANTE MAGNETICO MOTOR DUCATI 390CC
P13	6	D35M390/P13/6	TORNILLO MOTOR DUCATI 390CC
P13	8	D35M390/P13/8	BOBINA DE ARRANQUE MOTOR DUCATI 390CC



P14

PAG	POS	REF.MIRAL	DESCRIPCION
P14	1	D35M390/P14/1	ACELERADOR MOTOR DUCATI 390CC
P14	2	D35M390/P14/2	MUELLE RETORNO GAS MOTOR DUCATI 390CC
P14	3	D35M390/P14/3	VARILLA GAS MOTOR DUCATI 390CC
P14	4	D35M390/P14/4	MUELLE REGULADOR MOTOR DUCATI 390CC
P14	5	D35M390/P14/5	BRAZO REGULADOR MOTOR DUCATI 390CC
P14	6	D35M390/P14/6	TORNILLO MOTOR DUCATI 390CC
P14	13	D35M390/P14/13	TUERCA MOTOR DUCATI 390CC
P14	14	D35M390/P14/14	TORNILLO MOTOR DUCATI 390CC